


REPAIR PARTS

SEARS TRIMMER MODEL 944.511560



WARNING

All repairs, adjustments and maintenance not described in the Operator's Manual must be performed by qualified service personnel.

Ref.	Part No.	Description	Ref.	Part No.	Description
1.	530054942	Assy-Throttle Cable	18.	530052285	Line Limiter
2.	530015886	Screw-handle/fan hsg	19.	530015805	Screw-Line Limiter
3.	530054837	Throttle Hsg. (Right)	20.	530015820	Bolt
4.	530071553	Kit-Left Throttle Hsg.	21.	530016118	Wingnut
5.	----	Assy-Front Wire	22.	530094543	Dustcup
	530054943	(A) Assy-Front Wire	23.	71-85640	Accy-Cutting Head
	530055724	(B) (Upper) Assy-Front Wire	24.	530095820	Cutting Head
6.	530015805	Screw-Alignment	25.	-----	Line
7.	530015886	Screw		71-85641	Green Line--(Grass)
8.	530054940	Trigger		71-85628	Red Line--(Grass/Weeds)
9.	530069572	Kit-Switch		71-85629	Black Line--(Weeds/Lt.Brush)
10.	530095261	Assist Handle	26.	530016296	Washer
11.	530015820	Bolt	27.	530016298	Nut-Shoulder (L.H.)
12.	530055126	Clamp-Assist Handle			
13.	530016152	Wingnut			
14.	530071607	Assy-Upper Shaft (incl.flex & coupler)			
15.	530016344	Screw			
16.	530071445	Assy-Lower Shaft (incl. flex shaft)			
17.	530069779	Kit-Shield Ass'y. (Incl.18-21)			
			Not Shown		
				530163193	Operator Manual
				530055599	Decal-Upper Shaft
				530055595	Decal-Shaft Warning
				530055568	Decal-Shield


REPAIR PARTS



WARNING

All repairs, adjustments and maintenance not described in the Operator's Manual must be performed by qualified service personnel.

SEARS TRIMMER MODEL 944.511560



Ref.	Part No.	Description	Ref.	Part No.	Description	Ref.	Part No.	Description
1.	530047721	Bulb-Purge	26.	530071400	Kit-Rope	50.	530015162	Ret.-Piston pin
2.	530015843	Screw-tank	27.	530032103	Bearing-Inner	51.	530025875	Ring-Piston
3.	530049858	Cap-Fuel	28.	530015787	Retainer	52.	530069899	Kit-Piston
4.	530095646	Assy-Fuel pickup	29.	530019158	Seal			(incl. 50-51)
5.	530071404	Kit-Fuel line	30.	530032102	Bearing-Outer	53.	530071401	Gasket-Cylinder
6.	530069216	Kit-Fuel/Purge line	31.	530015789	Ret.-Crankshaft	54.	530055727	Assy-Rear wire
7.	530015775	Screw	32.	530054948	Assy-Crankshaft	55.	530069310	Kit-Muffler
8.	530054935	Cover-Air box	33.	530014016	Assy-Crankcase	56.	530053346	Shield-Heat
9.	530054946	Filter-Air	34.	530055372	Assy-C'case/C'sft (incl.27-31,32,33)	57.	530036409	Spring-Muffler
10.	530015849	Screw-Carb.	35.	530071402	Kit-Flywheel Assy.	58.	530069626	Kit-Cylinder
11.	530054934	Box-Air	36.	530016030	Washer	59.	530001624	Plug-Spark(RCJ-8Y)
12.	530071405	Assy-Carb(WT597)	37.	530055620	Spacer	60.	530001624	Bolt-Cyl. (1/4-20")
13.	530071401	Gasket-Carb.	38.	530015775	Screw-Baffle	61.	530039218	Module-Ignition
14.	530055320	Assy-Fuel Tank	39.	530054939	Plate-Baffle	62.	530016357	Screw-Module
15.	530015771	Screw-Crankcase	40.	530016326	Screw-Rope	63.	530071401	Kit-Gasket (incl. 13,18, 53)
16.	530015952	Screw-Shroud	41.	530071399	Kit-Pulley(incl.40)			
17.	530054936	Shroud	42.	530042086	Spring-Starter			
18.	530071401	Gasket-Shroud	43.	530019182	Grommet	Not Shown		
19.	530027593	Valve-Reed	44.	530015810	Screw-F/hsg.		530055564	Decal-Model RH
20.	530029781	Stop-Reed	45.	530055536	Assy.-Fan Housing		530055565	Decal-Model LH
21.	530016064	Screw-Reed stop	46.	530094189	Washer-Clutch		530087868	Decal-Start Inst.
22.	530015875	Screw-Retainer	47.	530055122	Assy-Clutch			
23.	530055492	Isolator-Tank	48.	530028799	Assy-Clutch Drum			
24.	530054941	Ret.-Tank	49.	530010960	Assy-Conn. Rod			
25.	530054834	Handle-Starter						

REPAIR PARTS


SEARS TRIMMER MODEL 944.511560



WARNING

All repairs, adjustments and maintenance not described in the Operator's Manual must be performed by qualified service personnel.

Kit - Carburetor Assembly No. 530071405 - WT597



Ref.	Part No.	Description
1.	530069824	Carburetor Repair Kit (KIT= Indicates Contents)
2.	530038317	Limiter Cap-low (blue)
3.	530038318	Limiter Cap-high (red)
4.	530069844	Gasket/Diaphragm Kit (●=Indicates Contents)