


REPAIR PARTS

Sears Craftsman Convertible Cultivator Attachment - Model 944.511580



⚠ WARNING

All repairs, adjustments and maintenance not described in the Operator's Manual must be performed by qualified service personnel.

Ref.	Part No.	Description	Ref.	Part No.	Description
1.	530016363	Retainer-Hairpin	12.	530016366	Bolt-Washer Head
2.	530016362	Pin-Clevis	13.	530071479	Kit-Guard
3.	530071482	Kit-Gearbox	14.	530095960	Shaft-Flex
4.	530015515	Locknut	15.	530071513	Assy-Driveshaft
5.	530016375	Washer-Lock	Not Shown		
6.	530015209	Washer-Flat			
7.	530095987	Tine-Right Outside/Left Inside			
8.	530016364	Washer-Felt			
9.	530095986	Tine-Left Outside/Right Inside	545001432	Manual	
10.	530016374	Bolt-Hex	530150031	Hanger-Attachment	
11.	530015209	Washer-Flat	530055450	Decal-Shield	
			530055598	Decal-Shaft Warning	

A