


REPAIR PARTS

SEARS CANADA ELECTRIC TRIMMER MODEL 944.515120



⚠ WARNING

All repairs, adjustments and maintenance not described in the Operator's Manual must be performed by Qualified Service Personnel.

Ref.	Part No.	Description	Ref.	Part No.	Description
1.	530016120	Screw	20.	530015820	Bolt
2.	545012301	Assy-Housing Set w/decal	21.	530016152	Wingnut
3.	530404326	Assy-Motor	22.	530095776	Assy-Hub w/arbor (Incl. 23,24)
4.	530404385	Retainer-Cord	23.	530053241	Spring-Return
5.	530404386	Assy-Wire Harness (Incl. #6)	24.	530401957	Retainer-Spool
6.	530404396	Switch-Momentary	25.	530095845	Assy-Wound Spool
7.	530404165	Spacer	26.	530095846	Assy-TNG VI Head
8.	530400897	Washer	Not Shown		
9.	530404327	Fan-Cooling			
10.	530404325	Trigger-Switch			
11.	530071965	Kit-Upper shaft w/decal (Incl. #15)			
12.	530015786	Bolt-Handle			
13.	530058583	Assy-Handle (Incl. 12,14)	545001403	Manual - Operator	
14.	530016152	Wing nut	530150031	Attachment - Hanger	
15.	530016381	Screw	545002801	Decal - Model Warning	
16.	530071788	Kit-Lower Shaft	530150181	Decal - Shaft Warning	
17.	545014101	Kit-Shield (Incl. decal, 18,19)	530056220	Decal - Shaft Warning	
18.	530052286	Limiters-Line	545002901	Decal - Shield Warning	
19.	530015814	Screw			