


REPAIR PARTS



WARNING

All repairs, adjustments and maintenance not described in the Operator's Manual must be performed by qualified service personnel.

SEARS CANADA MODEL 944.517742



Ref.	Part No.	Description	Ref.	Part No.	Description
1.	530071459	Air Dam (kit)	22.	530056685	Housing-Left
2.	530071458	Gasket-Adapter (kit)	23.	530036792	Isolator-Crankcase
3.	530035561	Adapter-Carburetor	24.	530049491	Assy-Fuel Tank
4.	530016309	Screw	25.	530049527	Gasket-Fuel Tank
5.	530071458	Gasket-Carburetor (kit)	26.	530049386	Fuel Cap w/Retainer
6.	530071632	Kit-Carb Assy. (C1Q-W11C)	27.	530049656	Grommet-Shroud
7.	530056629	Air Box	28.	530069247	Kit-Line Carb/Purge
8.	530015849	Screw-Carb.	29.	530069216	Kit-Line Tank/Purge
9.	530049383	Air Filter	30.	530095646	Assy-Fuel Pick-up
10.	530056581	Air Filter Cover	31.	530071459	Grommet-Fuel line (kit)
11.	530016349	Screw			
12.	530056641	Guard-Muffler			
13.	530095469	Handle			
14.	530015886	Screw			
15.	530049323	Isolator			
16.	530071459	Foam-25.4mm (kit)		Not Shown	
17.	530015197	Nut			
18.	530016322	Knob-Blower		530163803	Operator Manual
19.	530056684	Housing-Right		530057414	Warning Decal
20.	530402044	Spring Cover Latch			
21.	530049617	Guide-Starter Rope			


REPAIR PARTS

SEARS CANADA MODEL 944.517742



WARNING

All repairs, adjustments and maintenance not described in the Operator's Manual must be performed by qualified service personnel.




Ref.	Part No.	Description	Ref.	Part No.	Description
1.	Champion	Spark Plug (RCJ-6Y)	28.	530071458	O-ring-C/case (kit)
2.	530015953	Screw	29.	530012443	Cover-Crankcase
3.	530055191	Insulator-Heat	30.	530015810	Screw
4.	530016387	Screw-Muffler-Internal	31.	530071459	Foam-219mm (kit)
5.	530015241	Screw	32.	530029182	Eyelet-Flange
6.	530071593	Kit-Spark Screen (incl. #5)	33.	530071467	Kit-Rope
7.	530071600	Kit-Muffler (incl. 4,5,6 & 8)	34.	530049488	Handle-Starter
8.	530071458	Gasket-Baffle (kit)	35.	530016326	Screw-Rope
9.	530071458	Gasket-Cylinder (kit)	36.	530095461	Assy-Mulch Blade
10.	530071457	Kit-Cylinder	37.	530626605	Nut
11.	530019182	Grommet-Ign. Module	38.	530402043	Spring-Return Cover
12.	530016357	Screw-Ignition Module	39.	530049313	Inlet Door
13.	530035505	Ignition Module	40.	530016240	Washer-Belleville
14.	530071357	Kit-Piston (Incl. 15 & 16)	41.	530069817	Kit-Impeller Ass'y.
15.	530055120	Piston Ring	42.	530056625	Seal - O-Ring
16.	530015162	Retainer-Piston Pin	43.	530016349	Screw
17.	530069945	Assy-Connecting Rod	44.	530055101	Housing-Pulley
18.	530071615	Kit-Crankcase Seal	45.	530042086	Starter Spring
19.	530055728	Outer Bearing	46.	530071466	Kit-Starter Pulley
20.	530015941	Retainer Ring-C'chaft	47.	530055102	Fan Housing
21.	530016190	Flywheel Spacer	48.	530015810	Screw
22.	530015149	Washer	49.	530071459	Foam-182mm (kit)
23.	530039209	Assy-Flywheel	50.	530071458	Kit-Gasket (Includes) (page 14 - #2 & 5) (page 15 - #8,9 & 28)
24.	530071456	Assy-Crankcase/Crank shaft (incl. 20,25,27)	51.	530071459	Kit-Foam (Includes) (page 14 - #1,16 & 32) (page 15 - #31 & 49)
25.	530012492	Assy-Crankcase (Incl. 18,19,26)			
26.	530032125	Bearing-Inner			
27.	530012452	Assy-Crankshaft			

REPAIR PARTS

SEARS CANADA MODEL 944.517742

Vacuum / Blower



KEY NO.	PART NO.	DESCRIPTION
1	530095564	Vac Bag w/Strap
2	530095470	Elbow-Vac Tube
3	530095589	Tube-Lower Vac
4	530056901	Tube-Upper Vac
5	530095593	Tube-Blower