

SEARS CANADA TRIMMER MODEL 944.518580



WARNING

All repairs, adjustments and maintenance not described in the Operator's Manual must be performed by qualified service personnel.

A

REPAIR PARTS

Briggs Engine MODEL 021032-0562E1

Note:

Cylinder and Internal Components are
NOT SERVICEABLE.
Use Replacement Engine





SEARS CANADA TRIMMER MODEL 944.518580

ENGINE PARTS



WARNING

All repairs, adjustments and maintenance not described in the Operator's Manual must be performed by qualified service personnel.




Ref.	Part No.	Description	Ref.	Part No.	Description	Part No.	Description
1.	---	Briggs Engine Model 021032-0562E1	18.	698050	Blower Hsg./Rewind (Incl. 19,21)		
2.	790885	Spark Plug	19.	699944	Grip-Starter Rope(Incl. Rope)		
3.	696891	Screw-Cyl. Head	20.	698031	Screw-Blower Hsg.		
4.	696848	Head-Cylinder	21.	791499	Assembly-Pulley/Spring		
5.	696865	Gasket-Cyl. Head	22.	696928	Nut-Flywheel		
6.	697040	Screw-Muffler Defl.	23.	696879	Seal-Oil		
7.	697039	Deflector-Muffler (Incl. #6)	24.	696930	Dipstick (Incl. o-ring)		
8.	697038	Arrestor-Spark	25.	697010	Kit-Engine Gasket Set		
9.	697035	Gasket-Exhaust	26.	698031	Screw-Cam Gear Cover		
10.	696874	Assy-Muffler (Incl. # 6,7,8,9)	27.	696871	Tube-Breather		
11.	696931	Gasket-Breather	28.	696967	Cover-Cam Gear		
12.	696849	Cover-Valve	29.	696929	Gasket-Cam Gear Cover		
13.	696889	Screw-Valve Cover	30.	696866	Gasket-Crankcase		
14.	696885	Assy-Flywheel	31.	696950	Cover-Crankcase		
15.	696877	Armature-Magneto	32.	696889	Screw-Crankcase Cover		
16.	696891	Screw-Magneto	33.	696936	Shield-Cylinder	275064	Manual-Owner's(B&S)
17.	698243	Switch-Stop	34.	696889	Screw-Cyl. Shield	275072	Manual-Repair(B&S)
			35.	696895	Screw-Cyl. Shield(A)	699969	Cup-Oil Fill(B&S)
						19538	Puller-Flywheel(B&S)


REPAIR PARTS

SEARS CANADA TRIMMER MODEL 944.518580

ENGINE PARTS



WARNING
All repairs, adjustments and maintenance not described in the Operator's Manual must be performed by qualified service personnel.



Ref.	Part No.	Description	Ref.	Part No.	Description
1.	696894	Screw-Carburetor	11.	696922	Gasket-Fuel Tank
2.	696868	Gasket-Intake	12.	696872	Insulator
3.	790567	Air Cleaner	13.	696919	Assy-Fuel Tank
4..	696923	Filter-Air Cleaner Foam			(Incl. 11,12,14,15)
5.	696867	Gasket-Intake	14.	696921	Cap-Fuel Tank
6.	696870	Spacer-Carburetor (Incl. 5)	15.	699876	Sleeve-Fuel Line
7.	696893	Screw-Carburetor Adapter			
8.	696949	Carburetor (Incl. 2,9)			
9.	699942	Seal-O-Ring (Carburetor)			
10	690800	Nut-Carburetor			